

EkaPad chords for a Macintosh computer with the U.S. Extended keyboard selected.

This Chart shows both the EkaPad chords and alternate chords for each symbol when the U.S. keyboard is selected on a Mac. Some symbols use the same chord.

When using an EkaPad some symbols can only be reached using the EkaPad chord; most symbols can be reached via two chord sequences

If you use a symbol frequently, choose the chord sequence which works most easily for you.

The chord sequences which rely on Option, Shift and/or NLock may be easier to use than the Mac's keyboard viewer.

x-ray views Mac U.S. Extended Cheat Sheet v E.6.0
Copyright © EkaTetra 2009 All rights reserved
ekatetra.com 503-697-0604

Help/insert Navigation includes Deletes Accent
P&R Accents +mark + letter or Space

Configs change settings; Config chord + 1st letter chord
OS select GridPad Reset FingerUp
OS=Config+o+m or w
Resets in blue 1st-Last

Code Create password with O set. Unlock Keeps with Code.
Code+password + KeepAccess
Q Set
Q Set+password + KeepAccess word+KAccess

Sleep Mac dialog box phone ten right left
Wake Npd+p 0 Npd+i 0 Npd+r 0 Npd+l 0
Mac: UnPlug EkaPad to wake

Trigger Repeat & Hold-Down
To hold down Shift, ⌘, Option, ctrl, Alt, press for Trigger delay time (0.5 sec-2 secs) and then release. To Repeat, hold down chord and release. P&R any key to exit. 9 = off
Config++ 1 to 8 sets delay time.

Version#
vert together Displays the current version of EkaPad software.

Functions
P&R F once for one digit function then P&R the number key(s)
P&R F twice for two digit function
Function numbers 1 through 24 work.
Restart = FF99 Restart stops & restarts computer

x-ray views Start here P&R = Press & Release
P&R boxed chord 1st - then P&R Caps if shown
For a chorded character P&R Caps = P&R chord with symbol %

Every command, prefix, & character (except one finger alphas and numerals) is available whatever the state.
x-ray views are thumb side views of keys & chords.

Right handed
s o t a e i h r n f k g j w b m p d l z y v c x q u

Left handed
period Space Return Tab comma NonBreak Space Enter esc P&R Alpha to return to lower case
@ * / + = - \$: ; { } []

NLock Backspace Delete Delete Caps CapsLock
P&R NLock to exit
NLock default layout is N pad p (phone)
Windows only Relic Print Scroll Lock Pause keyboard Power

EkaTetra 16580 Maple Circle, Lake Oswego OR 97034 USA

USB EkaPad Cheat Sheet: Macintosh U.S. Extended keyboard
Find additional Tools at www.ekatetra.com/support

x-ray views
Red symbols are diacritics and work with other letter & command chords.
Chords for Red & Blue symbols are different from US keyboard chords.

In the Mac, with the EkaPad and U.S. Extended keyboard selected, you can chord over 1000 letters and symbols. Check out the All Symbols.pdf to find the particular chords required to produce the characters. You'll need to use a Unicode font such as Arial Unicode M.

ShortCut & Keep
Store 99 ShortCuts & 99 Keeps. For 1 digit, Enter # entry Enter; for 2 digit, Enter Enter # # entry Enter. To retrieve: Access # or AA ##. To clear: Enter # Enter or EE## E.

ShortCut **Keep** **Code**
Enter Access Enter Access Code
0 all empty 0 all empty 0 Config + c

Code+password+KeepAccess unlocks Keeps if password protected.
Create 1 to 10 ShortCut sets, each with ten 1-finger chords.

To make it easy to access sets of ShortCuts for an application, organize them into ranges like 10,11,...19 or 50,51,...59 entering up to ten ShortCuts in a range. Accessed by 10-ones chord + first digit, each set gives repeated one finger access to ShortCuts in the range.

To Access a set of one finger ShortCuts:
P&R 10-ones, then P&R first digit of two digit location.
10-ones first digit repeated 1-finger chords
1-finger chord does More actions until exit with Alpha.
ShortCut stored in 2nd digit location

Names of State chords are colored: Alpha Navig NLock CapsLock ShortCut/Enter Keep/Enter GridPad 10-ones

Commands Primary: qwerty keyboard left side
R hand L hand or Ctrl or Alt P & RELEASE to activate commands CapsShift ShiftR
qwerty right side R or CtrlR OptionR ctrlR or wwR

Pressing any key completes and/or ends a command action

Post **PostCaps** **3postCaps** **3post same as Caps**
Use 3post for symbols with Caps in NLock or anywhere.

GridPad Numerical keypad on full size qwertyboards
Windows: Macintosh:
GridPad * / + - Enter =
Eject Up Down Volume F delete/ Clear
Alpha exits Gnum . period Windows only Numlock
Insert Home End Up Down Arrow Forward Delete
Left Right Up Down Delete

EkaPad U.S. Extended chords: Post, PostCaps, 3post Caps. Big Icons.

Red means this symbol is a diacritic, and different from the US cheat sheet.

Blue means this symbol is different from the US cheat sheet.

