

x-ray views

Cheat Sheet v 5.7

ekatetra.com Copyright © EkaTetra 2008 All rights reserved
503-697-0604

Helpers Navigation includes Deletes **Accent**

P&R Navig to exit + letter or Space

Configs change settings; Config chord + 1st letter chord

Config OS select GridPad Reset FingerUp

OS=Config+o+m or w 0 Resets in blue 1st-Last

Code Create password with **Q Set** If Alph On, EkaPad returns to AlphaState after 5 minutes of Off is default no chords

password with **password** **Alpha On/Off**

Q set. Unlock Keeps with Code.

Code+password **Q Set+pass-+ KeepAccess word+KAccess**

Sleep Npad (Config+n+letter)

Mac dialog box **phone ten right left**

Wake Npd+p 0 Npd+1 0 Npd+r 0 Npd+l 0

Mac: UnPlug EkaPad to wake

Trigger Repeat & Hold-Down

To bold down Shift, ⌘, Option, ctrl, Alt, press for Trigger delay time (0.5 sec-2 secs) and then release. To Repeat, hold down chord and release. P&R any key to exit. **9 = off**

Version#

ver together Displays the current version of EkaPad software.

Functions

P&R F once 3 2 1 P&R F twice 3 2 1 Function numbers 1 through 24 work.

for one digit 6 5 4 for two digit 6 5 4

function 9 8 7 function 9 8 7

then P&R the number key(s) 0

Restart = FF99

Restart stops & restarts computer

x-ray views Start here P&R = Press & Release

P&R boxed chord 1st - then P&R Caps if shown

1 For a chorded character P&R Caps P&R chord

2 with symbol % = +

Every command, prefix, & character (except one finger alphas and numerals) is available whatever the state.

x-ray views are thumb side views of keys & chords.

Right hand

Left hand

P&R Alpha to return to lower case

Backspace Forward Delete Delete Caps CapsLock

Nlock Delete Delete Caps CapsLock

P&R Nlock to exit Nlock default layout is N pad p (phone)

Windows only **Print Scroll Lock Pause Power**

Relic Screen Lock Pause Power

EkaTetra 16580 Maple Circle, Lake Oswego OR 97034 USA

USB EkaPad Cheat Sheet: Macintosh & Windows

Find additional Tools at www.ekatetra.com/support

x-ray views white symbols unique to each OS

blue symbols vary by font

Macintosh additional character set

Windows additional character set

ShortCut & Keep

Store 99 ShortCuts & 99 Keeps. For 1 digit, Enter # entry Enter; for 2 digit, Enter Enter # # entry Enter. To retrieve: Access # or AA ##. To clear: Enter # Enter or EE## E.

ShortCut

Enter Access Enter Access Code

Code+password+KeepAccess unlocks Keeps if password protected.

Create 1 to 10 ShortCut sets, each with ten 1-finger chords.

To make it easy to access sets of ShortCuts for an application, organize them into ranges like 10,11,...19 or 50,51,...59 entering up to ten ShortCuts in a range. Accessed by **10-ones** chord + **first digit**, each set gives repeated one finger access to ShortCuts in the range.

To **Access** a set of one finger ShortCuts: P&R **10-ones**, then P&R **first digit** of two digit location. **10-ones first digit** repeated **1-finger** chords

1-finger chord 3 2 1 More actions 3 2 1

does ShortCut 6 5 4 until exit with 6 5 4

stored in 2nd digit location 9 8 7 Alpha.

digit location 0

Names or State chords are colored: Alpha Navig

Nlock CapsLock ShortCut Enter Keep Enter GridPad 10-ones

Commands Primary: qwerty keyboard left side

⌘ or Ctrl Option ctrl or ww ShiftL

R hand L hand or Alt P & RELEASE to CapsShift

qwerty right side **AHR** or activate commands CapsShift

⌘R or CtrlR OptionR ctrlR or wWR ShiftR

Pressing any key completes and/or ends a command action

Post PostCaps 3postCaps 3post same as Caps

Use 3post for symbols with Caps in Lock or

GridPad Numerical keypad on full size qwertyboards

Windows: In Mac use Navig to move cursor.

Macintosh:

GridPad * / + - Enter =

Eject Up Down Mute Clear

Alpha exits Gnum • period Numlock

Windows only

0 Numlock switches between & #

Insert Home End Up Down

Arrow Forward Delete